

Single Phase Multifunction Din Rail Meter

SDM320C

User Manual V1.2



Zhejiang Eastron Electronic Co., Ltd.

Statement

All rights reserved. Without the written permission of the company, no paragraphs or chapters in this manual can be extracted, copied or reproduced in any form. Otherwise, the violator shall bear all consequences.

The company reserves all legal rights.

The company reserves the right to amend the product specifications in this manual without prior notice.

Before placing an order, please contact our company or local agent to get the latest specifications.

Catalogue

Chapter One. Product Overview

1.1 Product Introduction	3
1.2 Product Feature	3
1.3 Application Scenarios	3

Chapter Two. Technical Specification Parameters

2.1 Technical Parameters	3
2.2 Measurement Accuracy	4
2.3 RS485 Communication	4
2.4 Performance Standard	4
2.5 Outline and Dimension	5
2.6 Wiring Diagram	6

Chapter Three. Operating instructions

3.1 Panel Instructions and Key Operation Instructions	6
3.1.1 Panel Instructions	6
3.1.2 key Definitions	7
3.2 Measurement Parameters	7
3.3 Basic Setting	10

Chapter Four. Communication Introduction

4.1 Input register, function code (Hex) : 04	15
4.2 Hold register, function code (Hex) : 03/10	16
4.3 Read coil status, function code (Hex) : 01	19
4.4 Control coil, function code (Hex) : 05	19
4.5 For example	19

SDM320C

Chapter 1. Product Overview

1.1 Product Introduction

The SDM320C is a single phase multi-function remote control energy meter. It measures all important electrical parameters, such as Active Energy (kWh), Current (A), Voltage (V), Frequency(Hz), Power Factor, Power Demand, import and export energy etc. With built-in relay inside, the meter can be remotely controlled to turn on or off the electricity supply via RS485. The user can also set alarm objects and alarm level, once the alarm is activated the relay will be turned off automatically.

1.2 Product Feature

- Max.100A Direct Connect
- Multifunction Measurement, Displays Scroll Settings
- Support AMR, SCADA system
- Remote Control with Built-in Relay
- Energy Resettable
- White Backlit LCD Display
- Din Rail Mounting 35mm

1.3 Application Scenarios

The SDM320C is suitable for scenarios where remote control switches are required.

Chapter 2. Technical Specification

2.1 Technical Parameters

Input Voltage	Basic Voltage (Un):	230V AC L-N, 120V AC L-N
	Operating Voltage Range:	±20% of Un
	Measurement Form:	RMS
Input Current	Basic Current (Ib/ Iref):	5A
	Max. current(I _{max}):	100A
	Over Current Withstand:	20 I _{max} for 0.5s
Input Frequency		45-65 Hz
Insulation Capabilities	AC voltage withstand:	4KV/1min
	Impulse Voltage Withstand:	6kV – 1.2μS waveform
Power Consumption		≤ 2W
Pulse Port:		Can be Set (See Operating Instructions for Details)
Pulse Output Rate		1000imp/kWh(Default)
Display		LCD with White Backlit
Max reading		999999.99 kWh

2.2 Measurement Accuracy

- ◆ Voltage: 0.5%
- ◆ Current: 0.5%
- ◆ Frequency: 0.1%
- ◆ Power Factor: 0.01
- ◆ Active Power: 0.5%
- ◆ Reactive Power: 1%
- ◆ Apparent power: 0.5%
- ◆ Active Energy: Class 0.5s
- ◆ Reactive Energy: Class 2


2.3 RS485 Communication

- ◆ Bus Type: RS485
- ◆ Protocol: Modbus RTU
- ◆ Baud Rate: 1200/2400/4800/9600bps (Default)
- ◆ Address Range: 1-247 (Default:1)
- ◆ Max. Bus loading: 64pcs
- ◆ Max. Bus loading: 1000m
- ◆ Parity: EVEN /ODD/NONE (Default)
- ◆ Data Bit: 8
- ◆ Stop Bit: 1

2.4 performance standard

- ◆ Operating Humidity: $\leq 90\%$
- ◆ Storage Humidity: $\leq 95\%$
- ◆ Operating Temperature: $-25^{\circ}\text{C}\sim+55^{\circ}\text{C}$
- ◆ Storage Temperature: $-40^{\circ}\text{C}\sim+70^{\circ}\text{C}$
- ◆ International Standard: GB-T 17215/ IEC62053-22
- ◆ Accuracy Class: Class 0.5S
- ◆ Installation Category: CAT II
- ◆ Protection against Penetration of Dust and Water: IP51 (Indoor)
- ◆ Insulating Encased Meter of Protective Class: II
- ◆ Altitude: $\leq 2000\text{m}$


2.5 Dimensions




Height: 76.5 mm

Width: 96.5 mm

Length: 76 mm



2.6 Wiring diagram



Chapter 3. Operating instructions

3.1 Panel Instructions and Key Operation Instructions

3.1.1 Panel Instructions



After the correct connection, it will enter the normal measurement state, and the screen is displayed as follows:

1st Screen	Start up Screens: All Display Segments
2nd Screen	Start up Screens: Software Version
Failure Interface	Display fault code: the display interface of fault code and normal display interface automatic scrolling display, with the switching time of 3s. Error-01 indicates that the relay cannot close.

3.1.2 key Definitions:








	<ul style="list-style-type: none"> ◆ Measurement mode, short press: switch the display ◆ Setting mode: short press: switch menu or single-digit increases at the same level; Long press: return to the previous menu.
	<ul style="list-style-type: none"> ◆ Measurement mode, short press: invalid; Long press: enter the setting mode; ◆ Setting mode, short press: move the cursor (the cursor is flashing digital bit); Long press: menu item selection confirmation and parameter modification confirmation.








3.2 Measurement Parameters




View by pressing the button:

Total active energy → Import active energy → Export active energy → Total reactive energy → Import reactive energy → Export reactive energy → Voltage → Current → Active power → Power factor → Frequency → Maximum total active power demand → Communication Address → Communication Baud Rate → Communication Parity → Pulse Constant → Software Version


Page	Display	Description
1		Total active energy Example energy: 120.00kWh Represents relay open
2		Import active energy Example: 60.00kWh
3		Export active energy Example: 60.00kWh
4		Total reactive energy Example: 200.00 kVArh

5		<p>Import reactive energy Example: 100.00 kVArh</p>
6		<p>Export reactive energy Example: 100.00kVArh</p>
7		<p>Voltage Example: 230V</p>
8		<p>Current Example: 50.809A</p>
9		<p>Active power Example: 1.800kW</p>
10		<p>Power factor Example: 1.000</p>
11		<p>Frequency Example: 50.00hz</p>

12	 <p>The LCD display shows 'MD' at the top, followed by '2.680 kW' in large digits. A small downward arrow is positioned above the 'Total' label at the bottom of the display area.</p>	<p>Maximum total active power demand Example: 2.680kW</p>
13	 <p>The LCD display shows 'Addr' at the top, followed by '001' in large digits. The 'Total' label is at the bottom.</p>	<p>Communication Address Example: 001</p>
14	 <p>The LCD display shows 'bd' at the top, followed by '9600' in large digits. The 'Total' label is at the bottom.</p>	<p>Communication Baud Rate Example: 9600 bps</p>
15	 <p>The LCD display shows 'Parity' at the top, followed by 'N' in large digits. The 'Total' label is at the bottom.</p>	<p>Communication Parity Example: N (None) Note: N represents none; E represents even; O represents odd</p>
16	 <p>The LCD display shows 'PLS' at the top, followed by '1000 kWh' in large digits. A small downward arrow is positioned above the 'Total' label at the bottom.</p>	<p>Pulse Constant Example: 1000imp/kWh The current output mode of the optocoupler pulse is total active energy mode</p>
17	 <p>The LCD display shows '02 01.00' in large digits. The 'Total' label is at the bottom.</p>	<p>Software Version Example: 02 01.00</p>
18	 <p>The LCD display shows 'ERR-01' in large digits. The 'Total' label is at the bottom.</p>	<p>The failure interface Example: ERR-01 Automatic display when fault occurs, and ERR-01 represents the relay cannot open.</p>

19		<p>Over-limit alarm interface</p> <p>In the measurement interface, if the upper right corner</p> <p>appears  and , it indicates that the measured value of the alarm object exceeds the alarm value.</p> <p>The relay can be closed manually or by modbus communication after the troubleshooting.</p>
----	---	--

3.3 Basic Setting

Long press "  " for three seconds to enter the setting mode.






Note: If there is no operation in 1 minute under the setting mode, the meter will exit the setting interface and return to the display of total active power.
















Instructions: Press the right button for 3s to enter into the setting mode, which is password protected and need to input the correct password.

















Under the setting mode, press the left button for 3s to exit the setting mode.



















Under the setting mode, press the right button for 3s to enter/confirm the setting. Short press on the left button to choose the setting;










Under the setting mode, short press on the left button to scroll or change the setting item;





Page	Display	Description
1		Set successful, display: good
2		Setting failed, display: err
3		<p>Password</p> <p>Enter password into the Settings screen</p> <p>Default password: 1000</p> <p>Press  select number, press  select shift.</p> <p>Then long press to enter the setup</p>

		system.
4		Communication Address Default Communication Address: 001 Communication address range: 001~247
4-1		Long press  into the communication address setting interface, the current character flashing. Then, press  select new communication address. Finally, long press  to confirm Settings.
5		Baud Rate Default baud rate: 9600bps Baud rate range: 1200, 2400, 4800, 9600.
5-1		Long press  enter baud rate setting interface, the current character flashing. Then, press  select the new baud rate. Finally, long press  confirm Settings.
6		Parity Bit Default: None Optional: None, Even, Odd
6-1		Long press  enter the parity bit setting interface, the current character flashing. Then, press  select the new parity bit. Finally, long press  confirm Settings.

7		<p>Pulse Constant Default: 1000imp/kwh Optional: 1000, 100,10,1.</p>
7-1		<p>Long press  into the constant setting interface, the current character flashing. Then, press  select the new constant. Finally, long press  confirm Settings.</p>
8		<p>pulse width Default: 100ms Optional:200, 100,60. If the pulse constant is equal to 1000imp/kWh, the setting interface cannot be set to 200ms at this time.</p>
8-1		<p>Long press  enter pulse width setting interface, the current character flashing. Then, press  select the new pulse width. Finally, long press  confirm Settings.</p>
9		<p>Pulse output type Default: P (Total active energy) Option: P: Total Active Energy Q: Total Reactive Energy</p>
9-1		<p>Long press  into the pulse output type setting interface, the current character flicker. current charact Then, press  select the new pulse output type.Finally, long press  confirm Settings.</p>
10		<p>Demand cycle Default: 60 min Demand cycle range: 0-60min. 0 represents real-time update demand.</p>

10-1		<p>Long press  into the demand period setting interface, the current character flicker. Then, select  a new demand cycle. Finally, long press  ok Settings.</p>
11		<p>Clear the maximum demand Enter this setting to clear the maximum demand.</p>
11-1		<p>Long press  enter the maximum demand reset setting interface, the current character flicker. Finally, long press  to confirm zero clearing.</p>
12		<p>Auto wheel display time Default: 0s (without round show) Rotation time range: 0~30s</p>
12-1		<p>Long press  enter auto wheel display time setting interface, the current character flicker. Then, press  select the new auto wheel display time. Finally, long press  confirm Settings.</p>
13		<p>Backlight lighting time Default: 60 min optional: off,on,5,10,20,30,60,120 Off means that the backlight is turn off ; on means that the backlight is turn on.</p>
13-1		<p>Long press  into the backlit time setting interface, the current character flicker. n, press select the new backlight lighting time. Finally, long press  to confirm Settings.</p>

14	 <p>The LCD display shows 'PR5' on the left and '1000' on the right. Below the display is a dark bar with the word 'Total' in white text.</p>	<p>User Password Default: 1000 optional: 0 ~ 9999</p>
14-1	 <p>The LCD display shows 'PR5' on the left and '1000' on the right. The second zero is flashing. Below the display is a dark bar with the word 'Total' in white text.</p>	<p>Long press  to enter the user password setting interface and the current character flashes. Then, click on  the new User Password. Finally, long press  to confirm Settings.</p>
15	 <p>The LCD display shows 'AL' on the left and 'PRPR' on the right. Below the display is a dark bar with the word 'Total' in white text.</p>	<p>Check alarm information Enter this setting to check alarm associated information: Voltage 、 Current 、 Active power 、 reactive power 、 apparent power 、 Frequency</p>
15-1	 <p>The LCD display shows 'U1' in the center. Below the display is a dark bar with the word 'Total' in white text.</p>	<p>Alarm object Default: NULL (No alarm object) Note: this option can only be set via communication</p>
15-2	 <p>The LCD display shows '280' on the left and 'V' on the right. Below the display is a dark bar with the word 'Total' in white text.</p>	<p>Alarm Value Default: 100000.0 Note: this option can only be set via communication</p>
15-3	 <p>The LCD display shows 'RLY' on the left and 'OFF' on the right. Below the display is a dark bar with the word 'Total' in white text.</p>	<p>Relay Control The display status of this option is off for relay open and on for relay close. This option can be set only if the alarm occurs when the relay automatically disconnects. Set relay close through this option, which means manually disarming the alarm. Therefore, before you do this, make sure the alarm object is troubleshooting.</p>

15-3-1		<p>Long press  enter relay status setting interface, current character flicker. Then, press  select the new relay status. Finally, long press  to confirm settings..</p>
--------	---	--

Chapter 4. Communication Introduction

4.1 Input register, function code (Hex) : 04

register Serial number	Enter register parameters				Register start address Hex	
	parameter-definition	data length (bytes)	data format	unit	high byte	low byte
30001	Voltage	4	Float	V	00	00
30007	Current	4	Float	A	00	06
30013	Active power	4	Float	W	00	0C
30019	apparent power	4	Float	VA	00	12
30025	reactive power	4	Float	VAr	00	18
30031	Power factor (1)	4	Float	None	00	1E
30037	phase angle	4	Float	Degrees	00	24
30071	Frequency	4	Float	Hz	00	46
30073	Import Total active energy	4	Float	kWh	00	48
30075	Export Total active energy	4	Float	kWH	00	4A
30077	Import Total reactive energy	4	Float	kVArh	00	4C
30079	Export Total reactive energy	4	Float	kVArh	00	4E
30081	Total apparent power	4	Float	kVAh	00	50
30085	Active power demand (2)	4	Float	W	00	54
30087	Max.Active power demand (2)	4	Float	W	00	56
30101	apparent power demand	4	Float	VA	00	64
30103	Max.apparent power demand	4	Float	VA	00	66
30109	reactive power demand (2)	4	Float	VAr	00	6C
30111	Max.reactive power demand (2)	4	Float	VAr	00	6E
30259	Current demand	4	Float	A	01	02
30265	Max.Current demand	4	Float	A	01	08
30343	Total active energy	4	Float	kWh	01	56
30345	Total reactive energy	4	Float	kVArh	01	58

Remark:

(1) the Power factor display will be adjusted automatically according to the Current direction.

Negative value indicates export Current, while positive value represents import Current.

(2) The default power demand = the forward value - the reverse value.

4.2 Keep register, function code (Hex) : 03 / 10

Register	Parameter	Register start address (Hex)		Description	mode
		high byte	low byte		
40003	Demand cycle	00	02	The set range:0~60 Unit: minute Default:60. 0 represent real time updates, i.e. update every second. data length : 4 byte data type : Float	r/w
40005	Sliding time	00	04	The set range: 1 ~ (demand cycle-1) unit:min Default1. data length : 4 byte data type : Float	r/w
40013	Pulse 1 output pulse width	00	0C	The set range: 60, 100, 200 Unit : ms Default: 100. Note: if Pulse Constant of pulse 1=1000imp/kWh, the pulse width will be fixed at 35mS and is not configurable. data length : 4 byte data type : Float	r/w
40019	Parity and stop bit	00	12	Set range: 0~3; Default: 0 0 = 1 stop bit, none parity. 1 = 1 stop bit, even parity; 2 = 1 stop bit, odd parity; 3 = 2 stop bits, none parity. data length : 4 byte data type : Float	r/w
40021	Modbus address	00	14	The set range: 1~247 Default: 1 data length : 4 byte data type : Float	r/w
40023	Pulse1 Pulse Constant	00	16	The set range: 0~3; Default: 0 0 = 1000 imp/kWh 1 = 100 imp/kWh 2 = 10 imp/kWh 3 = 1 imp/kWh	r/w

				Note: if the Pulse width of Pulse 1 is 200ms, Pulse Constant cannot be set to 1000 imp/kWh. data length : 4 byte data type : Float	
40025	Password	00	18	The set range 0000 ~ 9999. Default1000 data length : 4 byte data type : Float	r/w
40029	Baud rate	00	1C	Baud rate could be set to: 0, 1, 2, 5, Default2. 0 = 2400 bps 1 = 4800 bps 2 = 9600 bps 5 = 1200 bps data length : 4 byte data type : Float	r/w
40059	Automatic rotation time (Display)	00	3A	The set range 0~30; Default: 0. unit: s 0 = Automatic rotation display off. data length : 4 byte data type : Float	r/w
40061	Backlight time	00	3C	The set range 0 ~ 121; Unit: minute Default: 60. 0 = the backlight is always on; 121 = the backlight is always off data length : 4 byte data type : Float	r/w
40087	Pulse 1 output type	00	56	Values can be set: 2, 6, Default2. 2 = Total active energy. 6 = Total reactive energy. data length : 4 byte data type : Float	r/w
41025	Alarm object (1)	04	00	The set range: 0~5, and 255; Default: 255. 255 = no alarm object is associated. data length : 2 byte data type : unsigned int16	r/w
41027	Alarm value	04	02	The threshold value of the alarm is triggered. When the measured value of the alarm object is greater than the threshold value, the alarm is triggered and the relay will be automatically disconnected. Note: After an alarm occurs and the relay is automatically disconnected, it is necessary to manually issue a command to control the relay and close it to release the alarm.	r/w

				data length : 4 byte data type : Float	
461457	Clear historical data	F0	10	00, 00 = reset Max. demand info. data length: 2 byte data type: Hex	wo
463777	Measurement mode	F9	20	The value can be set: 0001 ~ 0005 00 01 : total kWh = Import kWh 00 02 : total kWh = Import kWh + Export kWh 00 03 : total kWh = import kWh – Export kWh 00 04 : total kWh = Export kWh 00 05: total kWh = Export kWh – Import kWh data length : 2 byte data type: Hex	r/w
464511	Meter fault code	FB	FE	00 00 = no failures 00 01 = the relay cannot open data length : 2 byte data type : Hex	ro
464513	serial number	FC	00	serial number of the meter data length : 4 byte data type : unsigned int32	ro
464769	Relay control command	FD	00	Values can be set: 00 00, FF 00. FF 00 = to contro the relay colse; 00 00 =to control the relay open; Note: when the alarm occurs, the relay needs to be closed through the command to remove the alarm. Length : 2 byte Data Format : Hex	wo

Note:**(1) Table-1 Alarm object**

reference number	Alarm parameter
0	Voltage
1	Current
2	Active power
3	reactive power
4	apparent power
5	Frequency

4.3 Read the coil status, function code (Hex) : 01

Register	parameter	Register start address (Hex)		values indicating	mode
		high byte	low byte		
00001	DO-1 status	00	00	1 = close 0 = open Note: DO-1 represents the relay inside the meter data length : 1 bit data type: Binary	ro

4.4 Control coil, function code (Hex) : 05

Register	parameter	Register start address (Hex)		values indicating	mode
		high byte	low byte		
00001	DO-1 control	00	00	FF 00 = to contro the relay colse; 00 00 =to control the relay open; Note: DO-1 represents the relay inside the meter data length :2 byte data type :Hex	wo

4.5 For example

Read the input register**Example: reading "Voltage"****Send: 01 04 00 00 00 02 71 CB****Where, 01 = modbus address of the meter****04 = function code****00 = high byte of Register start address****00 = low byte of Register start address****00 = high byte of register number****02 = low byte of register number****71 = low byte of CRC check code****CB = high byte of CRC check code****Return: 01 04 04 43 66 33 34 1B 38****Where, 01 = modbus address of the meter****04 = function code****04 = number of bytes returned**

43 = data, (high byte of high word)
 66 = data, (high word low byte)
 33 = data, (low word high byte)
 34 = data, (low byte of low word)
 1B = low byte of CRC check code
 38 = high byte of CRC check code
 Note: 43 66 33 34(Hex) = 230.2 (Floating point)

2. Read hold register

Example: read "slip time"

Send: 001 03 0004 0002 85 CA

Where, 01 = modbus address of the meter

03 = function code
 00 = high byte of Register start address
 04 = low byte of Register start address
 00 = high byte of register number
 02 = low byte of register number
 85 = low byte of CRC check code
 CA = high byte of CRC check code

Return: 01 03 04 40 A0 00 00 EF D1

Where, 01 = modbus address of the meter

03 = function code
 04 = number of bytes returned
 40 = data, (high byte of high word)
 A0 = data, (high low byte)
 00 = data, (low word high byte)
 00 = data, (low byte of low word)
 EF = low byte of CRC check code
 D1 = high byte of CRC check code
 Note: 40 A0 00 00 (Hex) = 5 (Floating point)

3. Write hold register

Example: set "demand period" = 60 min

Send: 01 10 00 02 00 02 04 42 70 00 00 00 67 D5

Where, 01 = modbus address of the meter

10 = function code
 00 = high byte of Register start address
 02 = low byte of Register start address
 00 = high byte of register number
 02 = low byte of register number
 04 = number of bytes written to data
 42 = data, (high byte of high word)
 70 = data, (high word low byte)

00 = data, (low word high byte)

00 = data, (low byte of low word)

67 = low byte of CRC check code

D5 = high byte of CRC check code

Note: 42 70 00 00 (Hex) = 60 (Floating point)

Return: 01 10 00 02 00 02 E0 08

Where, 01 = modbus address of the meter

10 = function code

00 = high byte of Register start address

02 = low byte of Register start address

00 = high byte of register number

02 = low byte of register number

E0 = low byte of CRC check code

08 = high byte of CRC check code

4. Read the coil status

Example: read DO-1 status

Send: 01 01 00 00 00 01 FD CA

Where, 01 = modbus address of the meter

01 = function code

00 = high byte of Register start address

00 = low byte of Register start address

00 = read the high byte of the number of DO

01 = read low byte of the number of DO

FD = low byte of CRC check code

CA = high byte of CRC check code

Return: 01 01 01 01 E0 50

Where, 01 = modbus address of the meter

01 = function code

01 = the number of bytes returned

01 = data (DO state)

E0 = low byte of CRC check code

50 = high byte of CRC check code

Description: data 0x01 = 0000 0001 (Binary Value).

Bit 0 stands for DO-1 status.

Bit0 = 1, which means DO-1 is closed;

Bit0 = 0, which means DO-1 is disconnected.

5. Control coil

Example: control DO-1 becomes closed

Send: 01 05 00 00 FF 00 8C 3A

Where, 01 = modbus address of the meter

05 = function code

00 = high byte of Register start address

00 = low byte of Register start address

FF = DO control command data high byte

00 = DO control command data low byte

8C = low byte of CRC check code

3A = high byte of CRC check code

Return: 01 05 00 00 FF 00 8C 3A

Where, 01 = modbus address of the meter

05 = function code

00 = high byte of Register start address

00 = low byte of Register start address

FF = DO control command data high byte

00 = DO control command data low byte

8C = low byte of CRC check code

3A = high byte of CRC check code

IF you have any question, please feel free to contact our sales team.

Zhejiang Eastron Electronic Co., Ltd.

No.52, Dongjin Rd, Nanhu, Jiaxing, Zhejiang, 314000, China

Tel: +86-573-83698881 83698882

Fax: +86-573-83698883

Email: sales@eastrongroup.com

www.eastron.com.cn

www.eastrongroup.com

